


c	mm	3250	3250	3250	3250	3450	3450	3450
d	mm	380	380	380	380	605	605	605
e	mm	225	225	225	225	311	311	311
f	mm	234	234	234	234	219	219	219
g	mm	172	172	172	172	180	180	180
h	mm	209	209	209	209	207	207	207
i	mm	200	200	200	200	242	242	242
l	mm	2000	2000	2000	2000	2170	2170	2170
n	mm	1006	1006	1006	1006	999	999	999
o	mm	80	80	80	80	80	80	80
p	mm	1050	1050	1050	1050	1360	1360	1360
Raccords entrée/sortie des échangeurs	Ø	2" VIC	2" VIC	2" VIC	2" VIC	2" 1/2 VIC	2" 1/2 VIC	2" 1/2 VIC
Raccords entrée/sortie DS	Ø	1" 1/4 VIC	1" 1/4 VIC	1" 1/4 VIC	1" 1/4 VIC	1" 1/4 VIC	1" 1/4 VIC	1" 1/4 VIC
Raccords entrée/sortie RC100	Ø	2" VIC	2" VIC	2" VIC	2" VIC	2" VIC	2" VIC	2" VIC

1.21 Espaces techniques et positionnement

TCAEY 269÷2112

TCAETY-THAETY 269÷296

TCAESY-THAESY 269÷296




L1	mm	1500
L2	mm	2000
L3	mm	1500
L4	mm	1000

TCAETY-THAETY 2112÷2146

TCAESY-THAESY 2112÷2146

TCAEQY-THAEQY 2112÷2146



L1	mm	2000
----	----	------